


Experiment Description



Experiment Set Up


- Four pens with attached accelerometers are set in parallel onto a paper-covered glass plate
- The glass plate is moved in a given pattern under them.
- The resulting pattern is



Experiment Description

Observation Intervals:

- The pattern is divided into two segments: left movement and right movement
- For each segment four ranges are considered:
 - A. entire range (10Hz to 12500Hz)
 - B. range from 500Hz to 1000Hz
 - C. range from 1000Hz to 1500Hz
 - D. range from 7500Hz to 8000Hz




Feature Description

Each movement segment (left and right) will be converted from the time domain to frequency domain using FFT

Features for each range:

- Maximum amplitude
- Maximum "point energy"
- Position of max. amplitude frequency
- Total energy, integral over the whole range



For each movement segment (left and right):

8 combined features computed from the sum and the distance of the four measuring method over all four intervals


In total:

16 features for left movement, 16 features for right movement and 8 combined

Items Description

There are four pen types:

- **B** - wide (breit)
- **M** - middle (mittle)
- **F** - thin (fein)
- **EF** - extra thin (extra fein)



Source of the picture: <https://www.penchalet.com>

Extra:

- Each type of a pen has different behavior and different limits of the values of the features.
- During an experiment the pens of only one type are tested
- Due to mechanical influences the forces on every pen in the test machine is slightly different

